FM EMERGENCY RADIO TORCH

Functions:

- ▶ 0.5W SMD and 2 LEDs Torch
- ► Hand Crank Mobile Charger
- Siren
- ► Tuning FM radio.

Features :

- ► Hand Crank generate power or Type A USB input charging
- ► High dB Siren Alarm
- ► Lighting Mode: 2 LEDs-0.5W SMD-Off
- ► Hand Crank Mobile Charger
- ► Battery Power Key Switch

Main Technical Parameters

Lighting:

| The Max. Luminous Flux(0.5W SMD) | ≥30 Lm |
|--|-------------|
| The Max. Luminous Flux(2 LEDs) | ≥6 Lm |
| Working Time after Fully charge (0.5W SMD) | ≥4 Hours |
| Working Time after Fully charge (2 LEDs) | ≥10 Hours |
| Lighting Time after 1 minute Hand Crank Generate Power(0.5W SMD) | ≥10 Minutes |
| Lighting Time after 1 minute Hand Crank Generate Power (2 LEDs) | ≥20 Minutes |

Radio:

| FM Frequency Range | Better than 5 uV |
|---|------------------|
| Radio Time after Fully Charge | ≥5 Hours |
| Radio Time after 1 minute Hand Crank Generate Power | ≥10 Minutes |
| Output Charging Current | 250~400mA |

Siren Alarm:

| Siren Alarm Noise | ≥ 120dB |
|---|--------------|
| Siren Alarm Working Time | ≥ 70 Minutes |
| Siren Alarm Working Time after 1 minute Hand Crank Generate Power | ≥ 2 Minutes |

Others:

| Specification of Built-in Battery | 3.7V, 480mAH Polymer Li Battery |
|-----------------------------------|---------------------------------|
| Diameter of Built-in Speaker | Ф36mm |
| Motor | 2.5W |
| Input Voltage and Current | 5V and 0.45A |
| Output Voltage and Current | 5V and 0.4A |
| Fully Charge Time | Approx. 2 Hours |

Operation Method :

- Lighting: Press the "LIGHT" switch to turn on or off. Radio: "RADIO" Switch to turn on or off radio and adjust volume "TUNING" Switch "+" or "-" to select channel SIREN:Press the "SIREN" Switch to turn on or off.
- ► Input Charge
 - A: Hand Crank Generate Power

Battery Power Key Switch On, crank at 2.5 or 3 cycles per second, indictor LED go on red when input charging

B: Built-in Type A USB

Battery Power Key Switch On, connect built-in Type A USB with AC Adaptor, PC etc., indictor LED go on red when input charging and go on green after fully charge.

► USB Output Charge

Battery Power Key Switch Off, Mobile or digital devices' input USB cable connect with Item's USB output Port that in bottom, crank at 2.5 or 3 cycles per second.

Cautions:

- ► Do not look directly into LED as this may cause damage to your eyes
- This product is not a toy.
- Contains small parts not suitable for children under 5 years of age
- ► Turn off the light when input charge

Product Accessories:

