


SOLAR-ENERGY RADIO

INSTRUCTION




Cranking for charger:

Unlock the handle, hold the unit and crank the handle by another hand at the speed of 2 to 3 circles per second for about 1 minute, the indication is on to show on-charging.



Charge by solar-energy:

Put the unit under the sunshine or blazing light to charge the built-in battery, the indication is on to show on-charging.



Reception of a radio:

- * Turn the volume switch clockwise, a crack sound will heard to show power on, then turn to make a clangorous sound.
- * Turn "FM/AM/WB Switch" to find the wave band which you want.
- * Turn "tune knob" select station.
- * If the radio is inefficient, FM can draw out and turn the antenna, AM can turn the unit to improve the effect of radio.
- * Close the radio: turn the volume switch anticlockwise, a crack sound will heard to show power off.



- * Pay attention when you crank the handle to avoid to hurt finger and nail;
- * Don't put the unit in a high temperature and high dank place;
- * Crank it one time for not less than 1 minute per month so as to prolong the using life of the battery, the time for you to crank continuously not more than 10 minutes;
- * Try your best to avoid the pile, basement and so on which will affect the effect of the radio.
- * To avoid affecting the generating system and hurting your fingers, please don't crank it too hard.
- * Normally, the unit will become a little heated when cranking it for a long time. Also, there will be a little noisy while listening to the radio and cranking the unit at the same time.
- * Please don't listen to the radio with high volume when using earphone, it may hurt your ear.